

## Disabling Clutch Orifice of SUBARU IMPREZA GDB

CLUTCH ORIFICE mechanism has been installed as original function in SUBARU IMPREZA GDB to prevent a rapid clutch engagement.

However, this function might accelerate wear rate of the carbon disc or cause a slipping of the clutch, we recommend to disable the function by following procedure.

- 1) Please detach the clutch orifice, which located next to clutch operating cylinder.
- 2) Loosened a screw of the orifice on the operating cylinder side.
- 3) Please note that there are springs inside of the orifice.
- 4) Please remove the parts (2 springs and 2 plastic parts) from the orifice
- 5) Please make sure that washer is attached to the screw and tighten up the screw to prevent any leakage of clutch fluid.
- 6) Attach the orifice to the vehicle as before, and please extract air from the clutch tube to ensure that clutch works correctly.

